BURRO



THE WASTE HANDLING HERO!

FOUNDAME CONTROL SOUNDAMES ARETY. Fiddly fork attachments?

Sequence of operation:



1. Driver positions Burro so that push arm on base touches edge of skip. As fork truck is driven forwards, base of Burro slides back.



2. Base locks in fully open position. Contents automatically discharge into skip. Burro can be raised or lowered to further agitate contents.



3. Empty Burro is lowered to ground level where base panel closes automatically.



4. Burro is ready for another load. There are no chains or other fixings to remove.



Model	Width	Depth	Height	Nominal Volume	Price
	(mm)	(mm)	(mm)	(cu.m)	(£)
SBR01	1200	1200	1050	0.75	517.00
SBR02	1200	1200	1250	1.00	570.00

Prices exclude delivery & VAT

The *BURRO* TM is available from

MGK (Scotland) Ltd.

Polbeth Industrial Estate. West Calder, West Lothian, EH55 8TJ

Tel: 01506 871757 Fax: 01506 873400



No attachments heeded, just pick it in and away von 80 Driver never leaves the safety of his vehicle Rafe Of discharge Controlled directly by operator - No Confect the Cessary between operator and contents A Total for handling sharp or hardrone and a sharp or hardlons materials SCIAD INCIAI, SWAIF, Class, Industrial waste, Clinical waste, Swart, Orians, Houtsurial Rubbish etc...